

To Measure Size:

- Holding the arm straight out, measure the arm from the underarm to the wrist (without thumbhole). or to the palm (with thumbhole). This is the length you need.
- Measure the circumference of the bicep and the wrist. The Pedi-Wrap is intended to cover the full length of the patient's arm. It should not be fitted in the mid-bicep area or it will not provide adequate support or immobilization.

