

Height Right Chair


⚠️WARNING: Optional infant insert required when using tray or grabrail for children up to 3 years of age. (Tray & Grabrail sold separately)

- Never leave child unattended
- Always secure child in the restraint
- Always keep child in view
- The front edge of the footrest should never extend beyond the bottom edge of the front supports at floor level
- Secure straps tightly
- Never use as a stepping stool

⚠️WARNING: Prevent serious injury or death from falls or sliding out.

⚠️WARNING: The child should be secured in the high chair at all times by the restraining system. The tray is not designed to hold the child in the chair. It is recommended that the chair be used only by children capable of sitting upright unassisted.

Parts



1

HARDWARE a (3pcs.)
 d (3pcs.)
 e (3pcs.)

Insert a Wooden Dowel (e) into the larger hole in each of the Back Supports and Front Support. Insert a Wood Nut (a), as shown into the inner holes of the 3 Supports. Attach the 3 Wooden Supports as shown and insert Long Screws (d). Loosely tighten the Long Screws into Wood Nuts through the Left Side with the Allen Key. Labeling on the Rear Supports should be visible.

FRONT SUPPORT IS SHORTER

Logos this side

2

HARDWARE a (1pcs.)
 d (1pcs.)

Insert a Wood Nut (a), as shown into the inner holes of the Back. Attach the Back as shown and insert a Long Screw (d). Loosely tighten the Long Screw into Wood Nut through the Left Side with the Allen Key.

3

a.

HARDWARE a (4pcs.)
 d (4pcs.)
 e (3pcs.)

Insert the rest of the Dowels, Wood Nuts, and Screws as needed to attach the Right Side of the chair. Do Not fully tighten screws.

b.


HARDWARE c (4pcs.)

Attach the 2 Metal Cross Bars as shown and insert Screws (c). Loosely tighten the Screws (c) into the Metal Cross Bars through Both sides with the Allen Key.

4


* As the child grows, the TOP metal cross bar CAN be removed.

Slide in the Seat and Foot Plate with the curved edges facing forward. Make sure that the Seat and Foot Rest are at the appropriate height for the occupant. See the Sizing section for proper placement of the Seat and Foot Rest.




• IF TOP METAL CROSS BAR IS NOT NECESSARY- START WITH # 2

5 TIGHTEN ALL SCREWS (BOTH SIDES) IN ORDER 1-5 _DO NOT OVER TIGHTEN!



HARDWARE_ b (4pcs.)


6 If the Tray or Grab accessories **ARE used**; Attach the Right Clip as shown in upper picture with 2 Small Screws (b). Repeat for Left. If Tray or Grab accessories **ARE not used**; Attach Black Caps with 2 small Screws (b). as shown in lower picture. Repeat for Left.



7b Second Safety Latch Engaged.
7a Primary Spring Lock

7a When Tray or Grab accessories are installed an audible "click" will be heard from primary lock.

7b Engage the second safety Latch Lever by pushing it forward into the primary spring lock.



Seat and Footrest Adjustment

Height

- The seat is placed at optimal height when the child's elbows are level with the top of the table.
- The foot plate is placed at optimal height when the child's foot can rest flat on it's surface.


Depth

- For optimal depth of the seat, position child's back against backrest with seat supporting 3/4 of thigh.
- For safety, the footrest should not exceed the front legs of the chair.

Teen / Adult Use


- Remove Seat Plate & Top metal cross bar.
- Use the Foot Rest as the Seat Plate for a larger seating surface.
- **Tighten all screws.**

3 Point Belt Installation



- Place child in seat. Crotch strap comes up between child's legs. Both Lap Straps come around child from center of back and "CLICK" into Crotch Strap. Adjust length of Lap straps to secure child in seat.
- Press center button on Crotch Strap buckle to release child from belt.

3 Point Belt Operation



5 Year Limited Warranty

Bergeron by Design warrants to the original retail purchaser of the Height Right Chair product, that if any part or component proves defective in material or workmanship within five years of the purchase date, the defective part will be repaired or replaced (at Bergeron by Design's discretion) free of charge. Warranty service may be performed by an authorized service center or at Bergeron by Design's discretion.

This warranty does not cover normal wear and tear, or damage caused by accident or misuse.

To exercise this limited warranty, the user should first obtain a Return Authorization Number from Bergeron By Design. The product must be delivered charges pre-paid (UPS recommended) to the factory or to an authorized service center, together with a copy of the original invoice, the Return Authorization Number and a written description of the problem.

Customer Service

Toll Free: 1.866.529.8407
International: 1.315.429.8407
Fax: 1.315.429.8862

Product Care

Clean chair with damp cloth; then wipe dry. With normal use, over time screws may loosen. Please maintain tight screws. **Use chair on level surface.**

Notice

When restraint system is used properly this high chair meets U.S. ASTM F-404 safety standard. Use only Height Right Chair accessories and parts. Height Right Chair parts are not interchangeable with other manufacturers' products. Replace any worn parts immediately for safety. © 2009 Bergeron By Design.



Bergeron By Design • 15 South Second St. Dolgeville, NY 13329 • 1.866.529.8407

Height Right Chair
Model # 0050002KR-0001

