

At Adaptive Star we believe in Going Out & Making A Difference We hope you will join us on our journey.

AXIOM Lassen

Indoor/Outdoor Mobility Pushchair Assembly and Care Manual Size 1.5, 2, 3 & 4



Frequently Asked Questions

Can | roller blade with my Axiom Lassen Push Chair?

We do not recommend this, it is just too easy to lose control and cause possible harm to your passenger or yourself

What if | break my Axiom Lassen Pushchair?

No problem! Just call us for help at 800-278-9626. We'll get you back up and on the road in no time.

Is the fabric on my Axiom Lassen Pushchair washable?

Yes! The seat, canopy and basket are removable and machine washable in cold water with mild detergent. After washing, place the seat back onto the Pushchair for drying. Machine drying in not recommended. Remember to remove the seat panels before washing and to replace them when you're finished.

Reminders

ALWAYS use your safety wrist strap any time a passenger is in the Pushchair.

ALWAYS engage rear food brake when loading and unloading a passenger.

NEVER leave a passenger unattended in or around the Pushchair.

NEVER overload the Pushchair. Overloading the Pushchair may cause it to become unstable and tip over.

DONOT allow your passenger to stand in the Pushchair. This may cause the Pushchair to tip and cause injury to the passenger, yourself or others.



Your AXIOM Lassen Pushchair is almost completely assembled when you receive it. The following short series of instructions will help you through the final few steps so you can get out and start having fun!



Remove all the contents of the box and confirm that they match the photo above If you determine that you are missing something, please call 1-800-278-9626 and talk with one or our helpful technicians.

First unfold your Axiom and place it into the upright position as shown here by pulling up on the handle until it locks in place.

Lets get started!



From this position ...



To upright and locked.



Make sure the units is unfolded and lock in place before loading the passenger and using the pushchair.



And finally....

Rear Wheel Installation

First unlock the rear foot brake by pulling the black loop upward





Next, push the black button and while holding it in...

...insert the wheel axle all the way into the pushchair frame and release the button. Now repeat to install the other wheel.





Check to make sure your wheels are locked in before each use.

Now you're ready to go!

However, we highly recommend that you read through the feature how to's, helpful suggestions and warnings throughout the rest of this manual

If you have any questions, just give us a call, we're here to help!



Folding your AXIOM Lassen...

Locate the Primary folding lockout release lever located on the left side upright of the AXIOM.

Prímary Release Latch I ever



Squeeze and hold the lever, while pushing down slightly on the AXIOM handle. Once the AXIOM has started to fold, you may release the lever.



Your AXIOM improv folds to a convenient size that will allow you to transport it in many automobile trunks. If you require a more compact folded size, simply remove the rear wheels.

When restoring your AXIOM Lassen to its upright and locked use position, be certain that there are no obstructions where the latch mechanism comes together. Make sure to confirm you have the Axiom Lassen locked into the upright position by pushing down on the handle





Things you need to know about.... Adjustable Height Handle

Your pushchair is equipped with a height adjustable handle. To adjust the handle to best suit your comfort, simply press the buttons located on the inside of the handle near the end of the foam handle grip. While holding the buttons in, adjust the handle up or down to the height that is correct for you. Once there, release the buttons and the handle will



The rear wheel parking brake works by pushing down on the black bar with the loop that runs between the rear wheels. It will lock into the black toothed hubs on the rear wheels. Make sure that it is engaged by pushing the chair back and forth slightly

lock into place.

Braking system



Always use the rear foot brake when loading and unloading your passenger. Always use the rear footbrake anytime a passenger is in the pushchair and you are not pushing or within reach of the pushchair.

Seat Anchor Straps

The seat harness system requires that the seat anchor straps be attached at all times. These straps are removable so that you can take off the seat for laundering etc. Please add this to your visual inspection prior to using the pushchair.

Wrist Strap

Your Axiom pushchair is equipped with a safety wrist strap. It is recommended that the wrist strap be used every time a passenger is in your pushchair to prevent it from accidentally rolling away from you unattended.



Never leave a passenger in the pushchair unattended <u>Always</u> use the wrist strap anytime a passenger is in the pushchair



Seat Recline

To recline the seat, simply slide the two straps behind the seat. To put the seat back to the upright position, pull the webbing taut until in the upright position.



Harness Adjustment

You will want to do a one time general positioning of the harness before placing the passenger in the seat. Once the passenger is in the seat then do the final harness adjustments as follows:

(Indo both the buckles from the padded center strap.



Push down on the silver center button located between the passengers knees and pull the webbing out to the end.



Pull up the webbing through the seat and up on the shoulder harness area.

Place the passenger in the seat.

Adjust the padded center strap forward or backward to fit your passenger.

Adjust the padded shoulder harness up or down on the Velcro strips to fit your passenger.

Buckle the two buckles to the padded center strap.

Pull the adjustment strap until the padded center strap and the padded shoulder harness are both snug. Adjust the chest strap to a comfortable length and connect the buckles.

If the harness is too small for the passenger harness extensions are available for purchase. A eminder.

Always check that the seat anchor straps are attached properly before each use.

Avoid serious injury from falling or sliding out; Always us the seat harness system



Maintenance

We recommend that you have an experienced dealer perform these maintenance check at least once each year. Lubrication of these following items is necessary:

- Insert in frame for rear wheels
- Wheel hub and bearings of front and rear wheels
- Locking bars of folding mechanism
- All folding joints of pushchair

Check to make sure all of the bolts are tight and that springs are secure on the rear foot brake.

Check fabric seams and straps for fraying and tearing.

Keep pushchair out of the sun and in a dry place when not in use, to prevent mold and mildew.

Check the frame for loose rivets, cracks and wear.

Check to make sure all nuts and bolts are tight on the frame.

We recommend that you put a rust preventative type coating on your wheels, nuts, bolts and brake springs on your pushchair. These parts can also be maintained by cleaning with a damp clothe and keeping these parts dry and free from debris.

The tires on the rear of your pushchair are a standard bicycle size and have an inner tube. In the event that one of your tires will not hold air, the inner tube can be replaced and both tires and inner tubes can be found at professional bicycle stores and most major retailers.



WARRANTYCARD

Thank you for purchasing an Adaptive Star Indoor/Outdoor Mobility Push Chair. We have created a warranty that will keep your unit in top condition and headache free. The following warranty is on workmanship and materials from the date of **original consumer** purchase:

- A 5-year warranty on the frame.
- A 1-year warranty on parts and soft goods.

Specific Exclusions

- Parts that require replacement under normal use.
- Damage or malfunction caused by negligence or abuse.
- Foam grips, inner tubes, tires, and rust are specifically excluded.

Adaptive Star will, at its option, repair or replace defective parts upon delivery to our service center accompanied by proof of date of first consumer purchase, such as a copy of a sales receipt. Please refer to the store where you made your purchase for returns and refunds as Adaptive Star does not give direct refunds. Purchaser is responsible for initial shipping charges required to ship the product for warranty service. Purchaser is also responsible for all applicable duties and/or custom charges. The return charges will be at Adaptive Star does not accept delivery of any product <u>without a Return Authorization #</u> clearly marked on the return shipment box and shipping label.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. Adaptive Star will not be liable for any incidental, consequential, or other damages, including, without limitation, damages resulting from loss of use. Some states do not allow limitations on how long an implied warranty last and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Your complete satisfaction is our goal. Please let us know if you are dissatisfied with any of our products. We will do our very best to correct the situation and make you happy. Feel free to contact us and send photos. We love to hear from you!

Adaptive Star, L	LC					
Po Box 369						
<u>S</u> elah, WA 9890	2 <u>customerservice@adap</u>	otivestar.com				
Telephone:						
FAX:	909-499-8926					
Name						
Address						
City		_State	Zíp	Phone		
E-Mail			,			
Model	1odel Date of Purchase					
Where did you	u purchase your ur	nít?				
Do you have suggestions for improvements to products?						
Are you interested in accessories?May we send you some information?						

